



1: Start



2: Load = Push



3: Unload = Pull

Important when loading:
Hold fuel cell towards the 90° edge

